

RHINO CARBON FIBER™ EPOXY GUN INSTRUCTIONS

For Dual Cartridge Epoxy Gun | Revision Date 05/05/2021

8383 Riley Street,
Zeeland, MI USA 49464
P: +1 888 684 3889
E: info@rhinocarbonfiber.com

01

01: PRODUCT IDENTIFICATION

This dispensing tool introduces maximum manual power combined with continuous flow for dispensing. The Rhino Carbon Fiber™ Epoxy Gun can easily be modified for use with either 300/300 ml or 300/150 ml dual cartridges.



- ALWAYS INSPECT PRODUCTS THOROUGHLY FOR DAMAGE OR MISSING PARTS BEFORE STARTING YOUR PROJECT.
- BLEED PRODUCT OUT INTO BIN OR ONTO PAPER UNTIL IT COMES OUT THOROUGHLY MIXED BEFORE USING.



Example of 300/300 ml dual cartridges

Small plunger



Example of 300/150 ml dual cartridges

Thumb release



Press thumb release plate and pull back to “open” epoxy gun

02: WARNING

- When switching the pushing plate from 300/300 ml to 300/150 ml, remember to always slide the pushing rod to the right (when holding the epoxy gun). If the pushing plate is not aligned evenly with the center of the 150 ml cartridge, the contents may unintentionally come out from the back end of the cartridge and cause harm.



1-888-684-3889 | www.RhinoCarbonFiber.com



20150

© All Rights Reserved

None of the authors, contributors, administrators, or anyone else connected with Rhino Products USA Inc. or any of its affiliates (collectively, “Rhino”), in any way whatsoever, can be responsible for your use of the information, instructions or advice contained in or linked from this or any related document. All liability with respect to actions taken or not taken based on the contents of this or any related document is hereby expressly disclaimed by Rhino. The content of this document is provided “as is;” no representations are made that the content is error-free.